



		<b>Audio Console</b>	
Input Selection	Master Section	Center portion of the mixer. It contains all master output controls.	
	Channel Strip	One vertical strip that contains all the controls for one channel	
Equalizer	Group	A Submaster for audio channels	
	<b>Channel Controls - In order from top to bottom</b>		
	Phantom Power	Sends power to the device plugged into the channel	
	Pad	Switches signal input from mic to line	
Auxillary	Gain	Adjusts the input level	
	Equalizer	Adjusts the tone of the input signal	
	EQ In	Makes the equalizer section active	
	Aux	Additional outputs for monitors or record	
	Pre Button	Makes the auxiliary section pre-fader	
	Pan	Routes signal left or right	
Playback	Mute	Mutes all outputs of the channel	
	Level Meter	Displays the strength of the input signal	
	PFL	Plays channel through the booth monitor	
	Routing Buttons	Sends the signal to the master section	
	Fader	Controls the output level of the channel.	